
Designing with off-the-shelf optics

Dmitry Reshidko

Prof. Jose Sasian


College of Optical Sciences

10/31/2016


Outline

- **Advantages** and **Disadvantages** of utilizing stock lenses.
- Various types of lenses have different capabilities for the **FOV** and **speed**:
 - Understand the limitations of stock lenses
 - Be aware of types of off-the-shelf optics
- “Best way” to utilize a stock lens for a particular application.


- Beam expander




- Cook Triplet



- 1x magnifier



- Optotune



Advantages of stock lenses

- **Cost:**
 - Stock lenses are made in larger quantities.
- **Speed:**
 - Optics production takes a lot of time.
 - Stock lenses are available for immediate delivery.
- **Easily replaceable components:**
 - Damage
 - Extreme use
- **Design for Education and Outreach**



Edmund Optics, Inc.

Disadvantages of stock lenses

- The need to select the optics from a **limited** list of available:


- Shape factors
- Focal lengths
- Sizes
- Glass (flint)

- **Less** control:



- Tolerances
- Specifications outside the defined areas

- Many lenses are sold **without** nominal prescription:

- Cheap optics
- Clearance products



What can be done?



- Our aim is to make our stock lens system as good as the available stock lenses will allow.
- As the rule of thumb, a system that covers the **FOV** of **5-20 degrees** at about **$f/6$** can be assembled from stock lenses.

Types of of-the-shelf optics

- **Components:**


- Singlets
- Doublets
- Mirrors
- Windows
- Prisms
- Filters

- **Sub assemblies:**


- Objectives
- Eyepieces
- Relays
- Photographic Lenses
- Machine Vision Lenses




Conjugates and shape factors



Field




Waveband




Infinite conjugate design

- Majority of components are designed for **infinite conjugate**:
 - PCX/Achromat lenses are designed for focusing a collimated beam
 - PCV lenses are designed to take a collimated beam and diverge it
- Breaking systems into separate infinite conjugate pieces will make fitting stock elements easier.
- Complex subassemblies like infinite conjugate microscope objectives can be substituted as a separate infinite conjugate piece of a larger system.




PCX PCV Doublet



Edmund Optics, Inc.


Finite conjugate design

- DCX and DCV are designed to relay a finite point to another finite point.
- These perform best when the object and image are equal distances from the lens and form a 1:1 relay.
- Very few component choices are available off the shelf that are designed for anything but an infinite conjugate or a 1:1 relay
- To achieve other finite conjugate relays it is best to use infinite conjugates together to form the relay system.




How to use a singlet


- Telescope objective type:



- Microscope objective type:




- Relay lens type:



High speed applications

- The limiting aberration in fast systems is **spherical aberration**.
- Using **two** lenses instead of one can reduce spherical aberration by a factor of 3 or so.




- Ideally both elements have the same power, and the sum of their powers equal to the sum of a single element they are replacing.


How to use a doublet

- Achromatic doublets are often designed to balance correction of color and spherical aberration and will have better results when used monochromatically.
- When used with object at infinity, doublets are often corrected for coma over a small FOV.

More strongly curved
surface towards the longer
conjugate





Doublet is followed by
the singlet



Wavebands


- When considering the waveband for an off the shelf component or assembly look at both the **color correction** and the **transmission**.
- Coatings** can have a significant impact on assemblies where many surfaces are used.
- If **broadband** information is **not needed**, the design can be **simplified** with the use of filtering or monochromatic illumination.



Edmund Optics, Inc.


Field correction

- Stock components **seldom** have any field correction built into them.
- Using **stop** placement and balancing Petzval powers can help reduce your field aberration.
- Keep field angles as **small** as possible -> Lengthening a design will usually **reduce** the field angles.
- If **large field angles** are needed, consider using off the shelf **assemblies** designed for the larger fields.



Sub-assemblies and Hybrid solutions

- **Replace** a component with a **subassembly** like a microscope objective or photographic lens.
- Use a **subassembly** with **components** to make a system solution.
- Use components to adjust parameters:
 - Conjugates -> weak positive lens
 - Focal length -> weak positive or negative lens





Edmund Optics, Inc.

Tips for designing with off-the-shelf optics


- Diameters:
 - There are a **finite number** of sizes available
 - **Larger** sizes than needed are often the best available option
- Lengths:
 - **Extending** the length allows the designs achieve smaller image angles which are easier to design around
 - One way to deal with size constraints in a design is adding **folds** with **mirrors** and **prisms**.
- Breaking designs into infinite conjugate segments typically allows better performance, but increase the length of the design.

Example: Laser beam expander

- A laser beam expander is a telescope used “back ward” to increase the diameter and to reduce the divergence of the beam:
 - Galilean form -> shorter, no internal focus
 - Keplerian form -> longer, internal focus, more difficult to correct
- Choose configuration to compensate and/or minimize spherical aberration.



Example: 1:1 relay




- 20mm Entrance Pupil and an approximately 100mm total track.
- Black is **polychromatic**, Blue E is **monochromatic**.
- Further improve by using **two sub-assemblies**.

Edmund Optics, Inc.

Fitting stock components into existing design

- Starting with an **optimized design** finding ways to replace custom elements with the closest stock options:
 - Start with **negative flint elements**
- Simplify:
 - Be as flexible on **size** as possible
 - Reduce **waveband** as much as possible
 - Look for closest fits, consider shape factors
- If a **non-symmetric** double convex or concave lens is needed, **split** it into two plano-convex or concave lenses with the plano sides touching each other
- Replace **one** at a time and **optimize** air gaps and radii



Built-in tools for fitting stock components


Stock element matching
tool in Zemax



Stock Lens Matching

- Open your existing lens.
- Set the Semi-diameters to automatic.
- Open Stock lens matching.
- Under “surfaces” select either “all” to replace all lenses, or “variables” to only change out the lenses you designate by putting a variable on the radii.
- Unless **size** is a big concern, use a large number for the EPD **tolerance%** to check more options.
- Check Air Thickness Compensation to adjust airspaces during optimization.

Fitting stock components manually




- Cook triplet from Zemax library.
- Check Edmund Optics and ThorLabs: only N-SF11 and N-BK7 is available.


Fitting stock components manually


Optical Lenses


Showing 1 - 14 of 14


Description ▾


**12.0mm Dia. x -12 FL, Uncoated, Plano-Concave Lens**
Stock #45-014
[Specifications and Documents](#) IN STOCK [Volume](#) **\$28.50** [Qty](#) [BUY](#)

**12.0mm Dia. x -15 FL, Uncoated, Plano-Concave Lens**
Stock #48-679
[Specifications and Documents](#) IN STOCK [Volume](#) **\$28.50** [Qty](#) [BUY](#)

**12.0mm Dia. x -18 FL, Uncoated, Plano-Concave Lens**
Stock #48-335
[Specifications and Documents](#) IN STOCK [Volume](#) **\$28.50** [Qty](#) [BUY](#)

**20.0mm Dia. x -30 FL, Uncoated, Plano-Concave Lens**
Stock #45-020
[Specifications and Documents](#) IN STOCK [Volume](#) **\$28.50** [Qty](#) [BUY](#)

**25.0mm Dia. x -25 FL, Uncoated, Plano-Concave Lens**
Stock #45-030
[Specifications and Documents](#) IN STOCK [Volume](#) **\$30.50** [Qty](#) [BUY](#)

**25.0mm Dia. x -35 FL, Uncoated, Plano-Concave Lens**
Stock #48-680
[Specifications and Documents](#) IN STOCK [Volume](#) **\$30.50** [Qty](#) [BUY](#)

Lens Catalogs

Search Criteria

Vendor(s): EDMUND OPTICS ▾
☒ Use Effective Focal Length (mm)
Min: -40 Max: -30
☐ Use Entrance Pupil Diameter (mm)
Min: 9.5 Max: 10.5
Shape: ☐ Equi- ☒ Spherical
☐ Bi- ☐ GRIN
☒ Plano- ☐ Aspheric
☐ Meniscus ☐ Toroidal
Of Elements: Singlet ▾

Search Results


45020 EFL= -30.00, EPD= 20.00 (P,S,1)
45021 EFL= -30.00, EPD= 20.00 (P,S,1)
45022 EFL= -40.00, EPD= 20.00 (P,S,1)
45023 EFL= -40.00, EPD= 20.00 (P,S,1)
45919 EFL= -30.00, EPD= 20.00 (P,S,1)
45919ink EFL= -30.00, EPD= 20.00 (P,S,1)
45920 EFL= -40.00, EPD= 20.00 (P,S,1)
45920ink EFL= -40.00, EPD= 20.00 (P,S,1)
47908 EFL= -30.00, EPD= 20.00 (P,S,1)
47908ink EFL= -30.00, EPD= 20.00 (P,S,1)
47909 EFL= -40.00, EPD= 20.00 (P,S,1)
47909ink EFL= -40.00, EPD= 20.00 (P,S,1)
48048 EFL= -39.98, EPD= 12.00 (P,S,1)
48052 EFL= -39.98, EPD= 12.00 (P,S,1)
48680 EFL= -35.01, EPD= 25.00 (P,S,1)

Selected 29 out of 6441 files.

Catalog Report Prescription Layout
Close Load Insert


- F2 $n_d=1.62$ $V=36.4$; SK-16 $n_d=1.62$ $V=60.3$
- N-SF11 $n_d=1.78$ $V=25.7$; N-BK7 $n_d=1.52$ $V=64.2$
- Negative element becomes weak: $f=-35\text{mm}$ is the weakest element I found.

Reoptimize the lens




- All lenses are plano- or bi-convex/concave.
- Split the negative element.
- We have some margin in performance.

Replace negative elements



- Flexible with lens sizes.
- Smaller negative lenses have shorter focal length. Sacrifice performance.
- Decent performance after replacing negative elements.


Final design



- All lenses from Edmund Optics catalog.
- Limiting aberration - Astigmatism.
- All elements have different diameter!

Optotune Lens Design Completion



Optotune



Starting point



U.S. Patent May 29, 1990 Sheet 1 of 15 4,929,066

Fig. 1





- Google Patent Search: “1:1 relay telecentric”
- R. Kingslake, “Lens design fundamentals”
- Smith, “Modern Lens Design”

Scale down and reoptimize




- Keep the lens symmetric – use Pick-Ups.
- All lenses are plano- or bi-convex/concave.
- The design meets spec monochromatically.
- The monochromatic design allows to learn about the **lens configuration**, **feasibility of the requirements**, and **dynamics of the optimization**.

Nominal configuration



- Insert the tunable lens.
- Remove the symmetry constraint.
- The design meets spec monochromatically at **f/12**.
- The lens is not symmetric anymore -> Need to control **Distortion!**

Final monochromatic design



- 3 configurations for 15mm tuning range.
- TIP: make MIN/MAX WD variable.
- TIP: let the magnification vary slightly for different configurations.




Multi-Configuration Editor

Update: All Windows

Operand 1 Properties

	Active : 1/3	Config 1*	Config 2	Config 3
1	MOFF -	NOMINAL	MIN	MAX
2	THIC 0	110.000	101.949 V	116.949 V
3	MOFF -			
4	CRVT 19	0.002	0.010	-0.007

Final monochromatic design



- Diffraction limited monochromatic performance.
- Distortion <0.08%
- Next step is chromatic aberration correction.

Chromatic aberration correction


U.S. Patent

May 29, 1990

Sheet 11 of 15

4,929,066

Fig. 21




- The patent provides some ideas.
- Replace singlets with doublets or maybe add more elements!

Summary


- Limitations of lens design with stock components:

FOV of 5-20 deg. at about f/6

- Types of off-the-shelf optics: PCX, PCV, DCX, DCV, Doublet
- “Best way” to utilize a stock lens for a particular application.



- Fitting stock lenses into existing design: **start with negative elements**



Questions?