Secondary Spectrum


Lens Design OPTI 517



Secondary Spectrum

The quadratic difference between the F and C wavefronts is:

$$\delta_{\lambda}W_{020} = \frac{1}{2}\sum \frac{y_m^2}{f\nu}$$



V- number

$$v = \frac{n_d - 1}{n_F - n_C}$$

$$\delta_{\lambda} W_{020} = \frac{1}{2} \sum_{m} \frac{y_{m}^{2}}{f \nu} = \frac{1}{2} \sum_{m} \frac{y_{m}^{2}}{f} \frac{n_{F} - n_{C}}{n_{d} - 1}$$



The quadratic difference between λ and F wavefronts is:

$$\begin{split} & \mathcal{S}_{\lambda} W_{020} = \frac{1}{2} \sum \frac{y_m^2}{f} \frac{n_{\lambda} - n_F}{n_d - 1} = \frac{1}{2} \sum \frac{y_m^2}{f} \frac{n_{\lambda} - n_F}{n_d - 1} \frac{n_F - n_C}{n_F - n_C} = \\ & = \frac{1}{2} \sum \frac{y_m^2}{f v} \frac{n_{\lambda} - n_F}{n_F - n_C} = \frac{1}{2} \sum \frac{y_m^2}{f v} P_{\lambda F} \end{split}$$


Where $P_{\lambda F}$ is the partial dispersion ratio from λ to F

For a system of thin lenses we have:

$$\mathcal{S}_{\lambda}W_{020} = \frac{1}{2}\sum \frac{y_m^2}{f\nu}P_{\lambda F}$$



Thin doublet




For a thin achromatic doublet:

$$f_a \cdot v_a = f_b \cdot v_b = F \cdot (v_a - v_b)$$


$$\delta_{\lambda} W_{020} = \sum \frac{y_m^2}{f v} P_{\lambda F} = \frac{y_m^2}{F} \frac{P_a - P_b}{v_a - v_b}$$

For zero secondary spectrum:




$$Tan(\varphi) = \frac{P_a - P_b}{\nu_a - \nu_b}$$

Partial Dispersion ratio vs. Abbe number



College of Optical Sciences





Prof. Jose Sasian



THREE-LENS APOCHROMAT

$$\sum vc\Delta n = \phi$$
 Power
$$c = \frac{1}{R_1} - \frac{1}{R_2}$$
 $\sum c\Delta n = 0$ Achromatism Secondary Spectrum where:

Or:

$$\begin{aligned} V_a & \left(c_a \Delta n_a \right) + V_b \left(c_b \Delta n_b \right) + V_c \left(c_c \Delta n_c \right) = \phi \\ & \left(c_a \Delta n_a \right) + \left(c_b \Delta n_b \right) + \left(c_c \Delta n_c \right) = 0 \\ & P_a & \left(c_a \Delta n_a \right) + P_b & \left(c_b \Delta n_b \right) + P_c & \left(c_c \Delta n_c \right) = 0 \end{aligned}$$

The solution to these equations is:

$$c_a = \frac{1}{FE(V_a - V_c)} \left\{ \frac{P_b - P_c}{\Delta n_a} \right\} \quad c_b = \frac{1}{FE(V_a - V_c)} \left\{ \frac{P_c - P_a}{\Delta n_b} \right\} \quad c_c = \frac{1}{FE(V_a - V_c)} \left\{ \frac{P_a - P_b}{\Delta n_c} \right\}$$


where F is the focal length of the triplet and E is:

$$E = \frac{V_a (P_b - P_c) + V_b (P_c - P_a) + V_c (P_a - P_b)}{(V_a - V_c)}$$

In the P-V diagram E is the 'sag' of the triangle defined by the points (Pa, Va), (Pb, Vb), and (Pc, Vc).



E is the 'sag' of the triangle defined by the points (Pa, Va), (Pb, Vb), and (Pc, Vc).



P-V Glass diagram Geometrical meaning of E




Single glass achromats

- Huyghenian eyepiece
- Maksutov meniscus
- Houghton corrector
- Field flattener
- Shupmann: dialytes (Kingslake p. 89-92)
- Shupmann medial telescope




Single glass achromats





$$\delta_{\lambda}W_{111} = \sum \frac{\overline{y}y}{fv} = 0$$



$$\delta_{\lambda} W_{020} = \frac{1}{2} \sum_{\nu} \frac{y^2}{f \nu} = 0$$











Shupman








Other forms are possible

See Kingslake

Patent literature on micro-lithographic


lenses



USP 5,835,275



Field correctors



Prof. Jose Sa

Sciences

Chromatic correction techniques


- Achromatize all elements
- Create two effective degrees of correction to correct two aberrations
- Phantom stop technique
- Symmetry of transverse color
- Change glasses with same Nd but different Abbe number
- Buried surface



Buried surface

- Paul Rudolph 1890
- Monochromatic design
- Split lens into a cemented doublet
- Chose second lens to have same index at nd but
 - different dispersion than first lens
- Monochromatic properties remain the same
- Change cemented interface radius to correct color
- SK-16 and F-9






Phantom stop

- Stop shift
- $\Delta\delta\lambda$ W020 = 0; $\Delta\delta\lambda$ W111 = 2 (δ yc/ ym) $\delta\lambda$ W020
- In the presence of axial color lateral color can be modified
- Correct lateral color by moving the stop
- Correct axial color at that stop position
- Move the stop back to the original position
- Color correction will be maintained



Achromatization of the Monochromatic Quartet

1990 International Optical Design conference problem
Note Aldis arrangement for controlling spherical aberration
Positive air lens
Example of optimization






Shupmann medial telescope

Single glass achromat

Mangin mirror

Field lens

Tilted components



Jim Daley
Designs in the US
See his book
Willmann-Bell




Chromatic aberration

- Monochromatic correction (may prepare for color correction)
 Chromatic correction
- Phantom stop to nullify lateral chromatic and find location to nullify axial chromatic
- Buried surface
- Use of a second interface to move location of phantom stop
- Use of the principle of symmetry to correct lateral color
- Chromatic aberrations as a black box: two aberrations; two degrees of freedom
- Chromatic variation (induced) of aberrations and use of multiple interfaces
- Sphero-chromatism
- Extreme case: all lenses are achromatic.



Sag comparison with new achromat



V-number for flint increases V-number for crown decreases

N for crown increases N for flint decreases

$$f_a \cdot v_a = f_b \cdot v_b = F \cdot (v_a - v_b)$$

F=100 mm




SSKN5-LF5 P=-219 mm




Chromatic performance

1000.000



Achromatic doublet




20 inch diameter

F/12


BK7

F4





Apochromatic doublet




20 inch diameter


F/12

FPL53

F4



Broken apochromat




20 inch diameer


F/12

BK7

KzFS1


Tlf2





Abbe number vs wavelength

V-number



$$v = \frac{n_d - 1}{n_F - n_C}$$




Example of double relay system









Relays for photography











Chromatic correction





Actual system



From Ronchigram simulation

From changing the Abbe mumberibys dences

Summary

- Glass properties
- Secondary spectrum
- Single glass achromats
- Phantom stop position
- Buried surface
- New achromat
- Apochromats

